


Appendix C – Water Meter



The above picture shows where the homeowner/IPOA irrigation line responsibilities are located at the lot taps.

Iron Bridge HOA Irrigation Taps
Tap Description and Winterizing Procedure



- 1— 1" Gate valve. This valve is used to isolate the homeowners mainline and/or in conjunction with Gate Valve 3 to isolate the Quick Coupler (2). **DO NOT** over tighten or try to open this valve to far, it will strip under unnecessary pressure.
- 2— Quick Coupler connection. From this point your system can be winterized through the meter for a short period of time. (5-10 seconds.)
- 3—1" Gate valve. This valve is used to isolate the homeowners mainline and/or in conjunction with Gate Valve 1 to isolate the Quick Coupler (2). **DO NOT** over tighten or try to open this valve to far, it will strip under unnecessary pressure.
- 4—This is a PRV valve (Pressure Reduction Valve.) Only qualified irrigation technicians should service this valve.